

RamDuct CAI Installation Tips

- If you plan to paint the RamDuct CAI, wash it thoroughly first with mild soap such as a dish soap that doesn't have hand softeners (usually the cheapest brands).
 - Most paints adhere well, including engine enamel, but you may want to test a non-visible area first
- If rain-water drainage is needed, you can drill a couple of ¼" holes or a 3/8" hole wherever the lowest area is for your installation (probably the rear unless you have a wedge spacer). These holes don't have a measureable effect on intake air temperature.
- If you have distributor or linkage interference, an air cleaner spacer can help. These can be found at auto parts stores, with the shortest size normally ½". Contact us at customerservice@fastlaneinnovations.com if you would need a custom spacer.



TIP: Overlapping Seal Ends



- Overlapping the ends of the seal when gluing provides a much stronger bond
- When cutting the seal to length, cut it $\frac{1}{2}$ " to $\frac{3}{4}$ " longer than needed. Then cut back the u-channel so it can butt together without cutting the flap so it can overlap. Then overlap the ends, glue, and press firmly for a minute or so.



Copyright 2015, Fast Lane Innovations, LLC.
All rights reserved.